


Step 1



- Push the 'Minus (-) Button' on your Nexia Bridge.
- The Nexia Bridge's Z-Wave Light will now blink a slow orange indicating that it is ready to unpair a product.

Step 2



- Turn the power switch of the lamp socket connected to the Aeotec Bulb 'OFF' and 'ON' quickly for a total of 3 times with the final state being 'ON'.
- The Aeotec Bulb will show an orange light for 2 seconds before showing a white light.
- The Nexia Bridge's Z-Wave Light will now blink a fast orange indicating that the unpairing process is taking place.

Step 3



- You have hereby successfully unpaired the Aeotec Bulb from the Nexia Bridge.