

## Step 1




- Push the 'Minus (-) Button' on your Nexia Bridge.
- The Nexia Bridge's Z-Wave Light will now blink a slow orange indicating that it is ready to unpair a product.

## Step 2



- Proceed by pressing on the 'Z-Wave Button' on the Aeotec Water Sensor.
- The Nexia Bridge's Z-Wave Light will now blink a fast orange indicating that the unpairing process is taking place.

## Step 3



- You have hereby successfully unpaired the Aeotec Water Sensor from the Nexia Bridge.