






Step 1





- Open the Harmony App on your mobile device.

Step 2




- Tap on 'Devices'.
- Tap on 'Edit Devices'.
- Tap on add '+ Device'.
- And tap on 'Zigbee/Z-Wave Devices'.

Step 3






- Proceed by touching the Yale Lock screen and inserting your personal master pincode followed by the pound '#' key.
- Then press '7' followed by the pound '#' key.
- Then press '1' followed by the pound '#' key.

Step 4



- The Harmony App will indicate that it has successfully found your Yale Lock.
- Tap on 'Done'.

Step 5



- You have hereby successfully paired your Yale Lock with a Logitech Harmony Home Hub with Extender.