



Step 1








- Open the Wink App on your mobile device.

Step 2






- Tap on 'Add a Product'.
- Search for 'z-wave'.
- And tap on 'Generic Z-Wave Binary Switch'.

Step 3






- Tap on 'Next' on the following 3 screens.
- And tap on 'Connect now'.
- The Wink Hub's LED will blink blue indicating that it is in pairing mode.

Step 4



- Proceed by quickly pressing 3 or more times on the Power Button of the EcoNet Valve Controller.
- The Wink App will indicate that it has successfully found the EcoNet Valve Controller.
- Tap on 'Done'.

Step 5



- You have hereby successfully paired the EcoNet Valve Controller with the Wink Hub 2.