





Step 1






- Open the Harmony App on your mobile device.

Step 2





- Tap on 'Devices'.
- Tap on 'Edit Devices'.
- And tap on the device which is associated with your Aeotec Water Sensor.

Step 3





- Tap on 'Remove Device'.
- Tap on 'Yes'.
- And tap on 'Remove device from Z-Wave network'.

Step 4



- Tap on 'Continue'.
- Proceed by pressing on the Z-Wave action button found at the back of the Aeotec Water Sensor.

Step 5



- The Harmony App will indicate that the Aeotec Water Sensor has been successfully removed from your Z-Wave network.
- Tap on 'Done'.
- You have hereby successfully unpaired the Aeotec Water Sensor from the Logitech Harmony Home Hub with Extender.