





Step 1







- Open the Harmony App on your mobile device.

Step 2






- Tap on 'Devices'.
- Tap on 'Edit Devices'.
- And tap on the device which is linked with your EcoNet Valve Controller.

Step 3




- Tap on 'Remove Device'.
- Tap on 'Yes'.
- Tap on 'Remove device from Z-Wave network'.
- And tap on 'Continue'.

Step 4



- Proceed by quickly pressing 3 or more times on the Power Button of the EcoNet Valve Controller.
- The Harmony App will indicate that it has successfully removed the EcoNet Valve Controller from your Z-Wave network.
- Tap on 'Done'.

Step 5



- You have hereby successfully unpaired the EcoNet Valve Controller from the Logitech Harmony Home Hub with Extender.