




Step 1






- Open the SmartThings App on your mobile device.

Step 2







- Tap on 'My Home'.
- And tap on the thing which is associated with your Schlage Lock.

Step 3





- Tap on the settings icon at the right top.
- And tap on remove on the following 2 screens.

Step 4



- Proceed by pressing on the 'Schlage' button at the front of the Schlage Lock followed by your unique programming code which you can find on the sticker on your instruction manual.
- Finish by tapping on '0' on the Schlage Lock.
- You will be shown a success message, a green check mark, on the Schlage Lock. Indicating that the unpairing process was successful.

Step 5



- The SmartThings App will show a confirmation message indicating that the device has been successfully removed from SmartThings.
- Tap on 'OK'.
- You have hereby successfully unpaired the Schlage Lock from the Samsung SmartThings Hub.