




Step 1





- Open the Wink App on your mobile device.

Step 2





- Tap on the settings icon at the right top.
- And tap on the thing which is associated with your Yale Lock.

Step 3





- Scroll down and tap on 'Remove this lock'.
- And tap on 'Remove'.

Step 4




- Tap on 'Next' on the following 2 screens.
- And tap on 'Disconnect now'.

Step 5



- Proceed by touching the Yale Lock screen and inserting your personal master pincode followed by the pound '#' key.
- Then press '7' followed by the pound '#' key.
- Then press '3' followed by the pound '#' key.

Step 6



- You have hereby successfully unpaired your Yale Lock from a Wink Hub 2.