






Step 1





- Open the Wink App on your mobile device.

Step 2





- Tap on the settings icon at the right top.
- Tap on the thing which is associated with your Aeotec LED Strip.
- Scroll down and tap on 'Remove this light'.
- And tap on 'Remove'.

Step 3





- Tap on 'Next' on the following 2 screens.
- And tap on 'Disconnect now'.

Step 4



- Proceed by pressing on the action button found at the back of the Aeotec LED Strip Controller.

Step 5



- The Wink App will indicate that the Aeotec LED Strip has been successfully removed from Wink.
- Tap on 'Next'.
- You have hereby successfully unpaired your Aeotec LED Strip from a Wink Hub 2.