

## Step 1



- Open the Nexia App on your mobile device.

## Step 2



- Tap on the 'Left Top Menu Button'.

### Step 3



- In the menu tap on 'Connect New Device'.

### Step 4



- Tap on 'Z-Wave Device'.

## Step 5



- Tap on 'Continue'.
- The Nexia Bridge's Z-Wave Light will now blink orange indicating that it is in pairing mode.

## Step 6



- Plug the Aeotec Siren into a power socket.

## Step 7



- Push on the 'Action Button' found at the bottom of the Aeotec Siren.

## Step 8



- The Nexia App will indicate that it has found the Aeotec Siren and that the pairing process has been successful.
- You have hereby successfully paired the Aeotec Siren with the Nexia Bridge.