

Step 1



- Open the Nexia App on your mobile device.

Step 2



- Tap on the 'Left Top Menu Button'.

Step 3



- In the menu tap on 'Connect New Device'.

Step 4



- Tap on 'Z-Wave Device'.

Step 5



- Tap on 'Continue'.
- The Nexia Bridge's Z-Wave Light will now blink orange indicating that it is in pairing mode.

Step 6



- Plug the Aeotec Siren into a power socket.

Step 7



- Push on the 'Action Button' found at the bottom of the Aeotec Siren.

Step 8



- The Nexia App will indicate that it has found the Aeotec Siren and that the pairing process has been successful.
- You have hereby successfully paired the Aeotec Siren with the Nexia Bridge.